



Assembly Instruction for Decorative Pole Sets for pole sets with wall brackets type 11950, 11952, 11954 and 11955

(A) Wall bracket assembly / installation:

Install the mounting plate (3) to the wall using the wood screws (2) and plastic dowels (1). Attach the bracket (4) onto the mounting plate (if using an additional bracket extension refer to (E) first). If any adjustment of the bracket is needed, loosen the recess screw (5) with the allen key (6), turn the bracket to the desired position and tighten the recess screw again. The length of the bracket stem can be cut to size (with a hacksaw) if necessary.

(B) Installation of the tubing:

Slide the tubing through the eye of the bracket. Then, using the recess screw (5) with the allen key (6), lock it into position. (Note: add desired amount of rings before going through each bracket).

(C) Finial / end cap assembly:

Slide the finial (7) onto the tubing. Lock finials with recess screw (5) using the allen key (6). Finials and end caps without recess screw

can be locked by a slight turn using light pressure.

(D) Recess bracket installation:

Drill hole and insert the plastic dowel (1). Attach the bracket (8) with the wood screw (2) and the tubing (10) with the recess screw (9).

(E) Bracket extension:

Loosen the recess screw (5) in the bracket and in the extension using the allen key (6). Remove the bracket from the base and insert the extension into the base, then attach the bracket. Lock both into place using the recess screw and allen key.

Note: although each installation screw includes a plastic dowel, we recommend mounting into studs. We accept no responsibility for damages caused by improper assembly / installation.